



18.410.48



1x



1x




2x





2x







1x




1x









SPAREPARTS			ERSATZTEIL-LISTE
Pos.	Art. Nr.	Description	Beschreibung
1	18.421.82	Cooking Grid	Grillrost
2	18.905.17	Handle set	Griff Set
3	18.421.83	Fire bowl	Feuerschale
4	18.421.84	Rear panel	Rückwand
5	18.421.85	Front panel	Vorderwand
6	18.421.86	Side panel	Seitenwand
7	18.905.18	Positioning screw set	Positionsschrauben Set
8	18.905.19	Foot pad set	Fussplate Set
9	18.421.87	Ash shovel	Aschenschaufel
10	18.905.20	S-Hook set	S-Hacken Set